



Alberta
User Manual



Before Use

Please fully charge our product before the first use. The charging time is about 3 hours, after it's fully charged, the LED light will stay on.

Please remove piercings or jewelry in the nipple, genital and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.


Product Specification

Product Name: Alberta Product No.: BX007 Material: Silicone, ABS Size: 73.5*50.3*51mm Weight: 87a±10a

Battery Type: Polymer lithium battery

Battery Capacity: 650mAh Charging Time: ≤3H Working Time: ≤50Min Vibration Mode: 5*5 Suction Mode: 5*3 Waterproof Rating: IPX6

Button Display



How to Use

Suction Mode

Press " O " button for 1.5s to turn on/off the suction mode.

Double-click the button " O " to switch 5 different suction modes.

Click the button " O " to switch 3 different suction intensity levels

Vibration Mode (Vibration Egg/ Nipple Clip)

*the mode cannot be activated without the vibration egg/nipple clip plugin

Press "__" button for 1.5s to turn on/off the vibration mode.

Double-click the button " \bigcirc " to switch 5 different vibration modes.

Click the button " $\hfill \bigcirc$ " to switch 5 different vibration intensity levels.

APP Remote Control

Turn on your phone's Bluetooth and connect the product to the official APP for remote control. (The APP can be downloaded by scanning the QR code attached)

Travel Lock Mode

Lock: In the off state, press and hold " " and " " for 8 seconds, the toy will enter the travel lock state, and all functions will not be triggered.

Unlock: In the lock state, press and hold " " and " " or 8 seconds, and the toy will be unlocked, and all functions can be used normally. (Charging can also be unlocked.)

Note: The toy cannot be turned on while charging, charging will make it shut down.

LED Display

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

Usage Instructions

Before using this product, please read this instruction manual thoroughly and understand the usage precautions, product features, and methods to ensure correct and safe use. Additionally, keep this manual in a safe place for future reference.

- Clean the product thoroughly before use with a water-based lubricant.
- If not used for a long time, clean it well and store it away from direct sunlight, high temperatures, and high humidity.

Charging

- Always use a standard charging AC adapter and the included charging cable. The fast-charging adapter may cause the built-in battery to deteriorate or fail to charge fully.
- Make sure the connection part does not get wet during charging.
- Ensure the charging time does not exceed 12 hours and monitor the charging process closely.
- Do not use the product while charging.

Maintenance

This product complies with the international waterproof standard and can withstand high-pressure water flow from any angle. Submerging it in water may cause malfunction. Wipe off any moisture and dry it completely after rinsing.

- If not used for a long time, store it away from high humidity and direct sunlight.
- Before the first time or after a long period of non-use, make sure to charge it once fully.

Warning

- As this is an adult product, keep it out of reach of children.
- If you experience skin allergies or discomfort while using the product, stop using it immediately and consult a doctor if necessary.
- If you find any malfunction or abnormal behavior, stop using it immediately and turn off the power.

Disposal

● This product contains a lithium-polymer battery. Do not dispose of it as household waste. When disposing, remove the battery and follow the disposal methods prescribed by your local authorities.

使用前

初めてお使いになる際は必ずフル充電を行ってからご使用ください。充電 時間は約3時間で、フル充電するとLEDランプが点灯します。

本製品を使用する前には、乳首や性器などのピアスやアクセサリーを取り 外Lで、本製品を洗浄・消毒してからご使用ください。ローションを使用する 場合は、水溶性ローションで製品とブライベートバーツをよく潤滑してくださ い。

製品仕様

商品名: アルバータAPP版

型番: VX007H

材質: シリコン、ABS樹脂

サイズ: 73.5mm x 51.5mm x 52.8mm

重量: 約98g±10g

定格電圧: 5V

定格電流: 1A

電池種類: リチウムポリマー電池

電池容量: 650mAh

充電時間: 最大3時間


稼働時間: 最低50分間

防水レベル: IPX4

振動モード: 5*5種類

吸引モード: 5*3種類

ボタン表示:



使い方

吸引モード

- 「 ()」を1.5秒長押しすると、吸引モードがオン/オフになります。

振動モード (ローター/クリップ)

※振動モードは先にローター/クリップに接続しておく必要があります。

- 「 」をダブルクリックすると、5種類の振動パターンが切り替わります。

アプリ操作について

- 1、BEYOURLOVER アプリケーションを先にダウンロードしてください。(ダウンロードは別紙参照)
- 2、先にスマホのBluetoothをオンに、BEYOURLOVER APPに登録し、 製品のボタンを長押しで接続してから遠隔操作が可能です。

旅行ロック機能

ロック: 電源がオフ状態で「 」と「 」を2秒長押しすると、赤
と緑のランプが交互に3回点滅し、ロックになります。
ロック解除: ロック状態で「 」と「 」を2秒長押しすると、青
と緑のランプが交互に3回点滅し、ロック解除になります。(充電中自動的
にロック解除します。)

※注意: 充電中は電源を入れることはできません。電源が自動的に切れます。

LED表示状態

動作中	LED点灯
電池残量低下	LED明滅
充電中	LED明滅
充電完了	LED点灯

ご使用上の注意事項

この製品をご使用になる前に、必ずこの取扱説明書を最後までよくお読みいただき、使用上の注意事項、本製品の機能や使用方法などを十分に理解して、正しく安全にご使用いただようお願いいたします。また、この取扱説明書は大切に保管していただき、今後の参照のためにお手元に置いておくことをおすすめします。 使用する前に製品をきれいに清潔し、水管性ローションと合わせて使用してください。 曼長時間に使用しない場合はよく洗浄し、専用の収納袋に収めてから、直射日光のあたる場所や高温、多湿になる場所を避けて保管してください。

充電について

●充電する際は必ず通常充電仕様のACアダプターと付属の充電ケー ブルをご利用ください。急速充電仕様のものをご利用する場合は、製品の 内蔵電池が多代されたり、フル充電できなかったりする恐れがあります。● 充電時は接続部が濡れないようにご注意ください。●充電時間は12時間 を放ったが、これでは、まない。また充電する際は必ず目を離さず、注 音監視してください。● 充電しながらでのご利用はおはかください。

メンテナンス

◆本製品はIPX4レベルの防水仕様のため、水中でのご使用はお避け下さい。浸水すると故障する恐れがあります。洗う時は、充電口などを避けて、水に掛からないようにしてください。また、吸引口はウェットティッシュで汚

れを拭き取ってください。もしくは吸引口を水で洗浄後、綿棒などで吸引口 の水をよく拭き取ってから、直射日光の当たらない所で保管してください。

●初めてご利用するときや長期間ご使用しなかった時は必ず一度満充 電にしてからご利用ください。

警告

- ●アダルトグッズのため、幼児の手の届かないところに保管してください。
- ●本製品を使用中に皮膚アレルギーや不快感を感じた場合は、直ちに使用を中止と、必要に応じて医師の診察を受けてください。● 放障が見つかったり、異常な動作を感じたら、直ちにご使用を中止し、電源を切ってください。

廃棄物処理

◆本製品はリチウムポリマー電池を内蔵しております。家庭ごみとして、処理しないでください。廃棄する場合は、電池を取り出してから各自治体の処理方法に従ってください。





BeYourLover公式アプリ 今すぐ無料ダウンロード!



