

TINGON Smart Space Capsule Automatic Masturbator M2

User Manual



Scan the QR code for more information





Ting | Enjoy More X

Focus On Dopamine Pleasure

TINGON dopamine toys are the ultimate in quality. With beautifully crafted designs guided by expert insight and extensive research, our collection has been created to empower people to explore a new world of intimate -and infinite – possibilities.





Safety Tips

- This product must not be washed or soaked directly in water. After use, please remove the telescopic silicone sleeve for cleaning. Do not wash or soak the device itself, as this may cause circuit damage or malfunction.
- This product is for personal use only and is not intended for use by other institutions or in public places
- This product is designed for private, personal use only and should not be used for any other purposes.
- Do not modify, disassemble, or repair this product yourself.
- Avoid dropping or striking the product. Do not use the product if it is damaged.
- Use a sufficient amount of lubricant when using the product to avoid discomfort.
- The product must not be exposed to moisture or water. Warning: Do not use this
 device near water-filled bathtubs, showers, washbasins, or other containers.
- Do not pull on the power cord or use it to drag the product.
- Always use original TINGON accessories compatible with this model.
- Do not place the product or its capacitor near high temperatures or heating devices such as sunlight, microwaves, heaters, or ovens. Overheating the capacitor may cause an explosion.
- Use this product within an ambient temperature range of 5°C to 35°C and store the product and its accessories within a temperature range of 5°C to 45°C.
- Store the product in a clean, dry place, away from direct sunlight, and out of reach of children.

Package Contents

1 masturbator main unit x1

2 USB-C charging cable x1



Product Details

Model	TINGON M2
Materials	PC+ABS+TPE
Dimensions	301.2*192.2*93mm
Net weight	1.3kg
Telescopic Mode	Stepless Extension and Retraction
Custom Mode	Unlimited Combinations, One-Touch Burst via Dual Pressure Sensors
TINGON APP	Available for download from the TINGON official website
Working Time	1-1.5 hour
Charging Time	4 - 4.5 hour
Operating Noise	<40-55decibels

TINGON APP




(Scan the QR code to visit the TINGON official website. Download the app based on your Android or Apple device. After successful registration, you can connect to all products in the series and enjoy more diverse features and synchronized interactive functions.)

Instructions for Use

Stroke Mode / Custom Range Switch Button



Dual Pressure Sensors (Enable One-Touch Burst Activation)



Power Control

- Press and hold the " or 1.5 seconds to turn the device on or off. Short press to pause or resume operation.
- Note: When powering on, keep holding the button until the device completes a reset movement, then release. The device will perform a reset operation automatically.

One-Touch Burst with Dual Pressure Sensors

The device has pressure sensors located on both sides at the front. When operating at speed level 2 or above, applying pressure to either sensor will activate the maximum power mode (burst mode). Releasing the pressure will return the device to normal intensity.

Stroke Switching / Custom Range Button

Short press to switch freely between the four basic movement ranges of the inner tank: upper, middle, lower, and full range. More movement ranges can be customized via the APP, which allows for setting ranges of any length and saving them permanently, with unlimited overwrites supported.

Speed Control Buttons


• Single press the" " to cycle through 4 speed levels. After reaching the highest speed, pressing again will cycle back down through the speeds.

Soothing Mode

Quickly double-tap the " to activate the slowest, gentle telescoping movement across the entire stroke.

Product Description





Precautions

First-time Use and Charging

- Before first use, fully charge the product.
- Correctly insert the configured USB-C charging cable into the charging port of the product for charging. During normal charging, the battery indicator light on the product screen will flash. When the battery is fully charged, the indicator light will stay on.
- Clean the product properly before use. Use warm water or a designated cleaner to wipe the parts that contact the body, then gently dry with a soft towel.

Applying Lubricant

 Apply a sufficient amount of lubricant on the soft silicone sleeve or the body contact areas for a comfortable and healthy experience. This product is only compatible with water-based, water-soluble lubricants.

Use Caution

 This product is not suitable for use on swollen or inflamed skin areas to avoid causing harm or exacerbating discomfort


Cleaning

• After each use, remove the soft sleeve and wash it thoroughly with warm water and antibacterial soap, rinse with clean water, and gently dry with a towel. Do not immerse the entire device in water for cleaning

Safety Precautions

 Do not operate the device while it is charging. Ensure the device is turned off during charging. Avoid charging near water sources.

Product Cleaning Instructions





- 1.Remove the soft silicone sleeve, disassemble and clean it thoroughly.
- 2.After cleaning thoroughly, air dry and then put it back into the sports compartment

Attention:

This product should not be used in humid environments and the cup body should not be directly rinsed. Daily maintenance only requires wiping with a damp cloth.



FCC Caution

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



挺昂智能伸缩太空舱飞机杯M2

使用说明书



扫描二维码获取更多资讯





Ting | Enjoy More

挺昂创造多巴胺愉悦

挺昂多巴胺玩具系列旨在让您沉浸于一个愉悦的、充满亲密感受和无限可能性 的新世界,为您带来绝妙的舒畅感受和独特体验。





安全提示

- 本产品不可直接水洗或冲泡,使用完毕后请取出伸缩软胶进行 冲洗清洁。切勿对机器直接水洗或冲泡,会导致电路断路或机 器失灵。
- 本产品为私人用品,不可用于其他机构或于公共场所使用。
- 本产品设计仅用于个人私密使用,请勿用于任何其它用途。
- 请勿自行改造、拆解或修理本产品。
- 请勿跌落或碰撞本产品,产品有损坏时禁止使用。
- 使用产品时请同时使用足量润滑油,以免身体不适。产品不能受潮或进水。警告:不要在盛水的浴缸、淋浴、洗脸盆或其他器皿附近使用本器具。
- 切勿用力拉扯电源线或使用电源线拖挂本产品。
- 请务必使用挺昂TINGON原装且与此型号设备配套的配件。
- 请勿将产品及其电容放置于高温处或加热设备的周围如日照、 微波炉、暖器、烤箱等,电容过热可能会引起爆炸。
- 请在环境温度5°C-35°C范围内使用本产品,并在温度5°C-45°C 范围内存放产品及其配件。
- 请将产品保存在清洁干净避免阳光直射并且儿童接触不到的地方。

包装清单

- ① 飞机杯主机x1台
- 2 USB-C充电线x1条

RoHS C € ⇔ 點 塗 fc

产品详情


产品型号	挺昂TINGON M2
材质	PC+ABS+TPE
尺寸	301.2*192.2*93mm
净重	1.3kg
伸缩模式	无极伸缩
自定义模式	无限组合、双压力感应一键爆发
TINGON APP	挺昂官方网站下载
工作时长	1.5-2小时
充电时长	4-4.5小时
工作噪音	<50db-55db分贝

TINGON APP



(扫描二维码进入挺昂官网页面,按安卓或者苹果机型进行APP下载。注册成功后即可进行 全系产品互联,及更加多样的玩法与同频互动功能)

产品使用说明



开关控制: 长按" (*)" 1.5秒进行设备开机以及关机,短按暂停/启动。注意开机时长按至机器进行复位运动即可放开(设备将进行复位操作)


一**键爆发双压力传感器**:设备前端左右各设一个压力传感器,2档速度以上任何行程中压力作用于此键,会进入最强档模式。松开按键回到普通强度。

切換/行程自定义按键:短按进行内胆上-中-下-全程区间的运动区间任意切换,一共4个基础运动区间。更多的运动区间可以通过APP端进行私人定制,APP端可以定制任意长度的运动区间并且永久保存,支持无限次覆盖。

速度按键: 单击加速键 " ← "进行速度调整,一共4个速度档位,到达最高档后继续按键后会依次降档。

舒缓模式:快速双击加速键 " 👇 "设备将在全行程下进行最低速慢伸缩运动。


产品描述



注意事项

- 1.首次使用产品前请先充电,请将配置的USB-C充电线正确插入产品的充电孔进行充电。正常充电时,产品 屏幕电量指示灯闪烁提示。当电池充满时, 电量指示灯长亮。产品使用前应做适当的清洁,可用温水或专 用清洁剂擦拭使用部位, 并用干毛巾轻轻擦干。
- 2.在器具软胶上或人体使用部位涂上足量的润滑剂,以达到健康愉快的效果。本产品仅适用水溶性润滑剂。
- 3、本产品不适用于肿胀或发炎的皮肤区域,避免伤害身体或加重不适。
- 4、每次使用后,需先拆卸取出软体,用温水和除菌香皂漂洗软体,再用清水冲洗干净,最后用干毛巾 轻轻擦干水份。不可连同设备整机浸泡清洗。
- 5、设备充电时不可运作,请勿在充电期间开机,请勿在靠近水的地方充电。

产品清洗







2.清洗干净后晾于塞回运动仓即可

注意事项:

本产品不可处于潮湿环境下使用, 亦不可直接冲洗杯体。 日常维护只需湿巾擦拭即可。

