

**SIXTH SENSE**  
說明書

**TW**

**使用前**

在第一次使用前,請將產品充滿電。充電時間約為1小時,充滿電後LED長亮。



使用前請將乳頭、生殖器和其他部位的穿孔或首飾摘下並對產品進行清潔和消毒。如使用潤滑液,請用水溶性潤滑液充分潤滑產品和您的私處。

**製品仕様**

產品名稱: SIXTH SENSE  
產品型號: HC549A  
材質: 矽膠, ABS  
尺寸: 85\*42\*24mm  
重量: 50±5g, 16g  
電池類型: 充電式聚合物電池  
電池容量: 150mAh  
額定電壓: 3.7V  
額定電流: <120mA  
充電時間: 1小時  
使用時間: 1小時  
振動模式: 10種類  
App模式: 6種類  
防水等級: IPX6

**如何使用**

**按鍵解析**

將該部分放在內褲外側來吸住穿戴部分,以更牢固貼合。

**開機/關機**  
長按 [ ] 鍵2秒,開啟/關閉電源。

**振動模式**  
點選 [ ] 鍵循環切換10種振動模式。

**遠端控制模式**  
點選 [ ] / [ ] 可切換10種不同的振動模式。  
點選 [ ] 暫停振動。點選 [ ] / [ ] 恢復振動。

**APP 遠端遙控功能**  
開啟手機藍牙功能,將產品連接到官方APP即可遠端控制。APP上更多不同的玩法:觸控模式、自動模式、聲音模式、音樂模式、異地模式和自創模式。(APP可從下面的二維碼中掃描下載)



**LED顯示狀態**

工作中	LED長亮
低電量	LED閃爍
充電中	LED閃爍
充滿電	LED長亮

**使用注意事項**

**充電**  
請使用官方廠商提供的充電器。充電線必須與玩具專用金屬接觸點上的磁性接點對接。如果充電線沒有黏在接觸點上,請將其連接到電源並稍等片刻。磁效應將被重新激活,觸點將自動連接。請保持充電座乾燥,以免影響磁性效應。充電時間不要超過12小時。

**維護**  
本產品符合IPX6國際防水標準,可從各個角度防止高壓水流。請勿在水下使用本產品。  
為獲得更好的體驗,請使用水溶性潤滑液。每次使用前後請清潔並在清洗後完全乾燥。請將其保存在安全乾燥的地方,避免陽光直射。

**警告**

如果您在使用本產品時出現皮膚過敏或任何不適,請立即停止使用,必要時請及時就醫。使用前請仔細閱讀說明書,並按照說明書安全使用產品。

**一年保固服務**

我們提供一年保固服務即從您購買產品之日起開始計算。如欲獲取保固服務請聯繫平台賣家或官方賬號,並提供有效的購買憑證。如有任何產品質量問題,請立即拍照留證,並在您的購買平台上附上訂單信息給賣家退換貨或提供信息並聯繫我們官方客服。更多資訊可訪問我們的推特賬號:@beyourlover\_HK或發電郵到afterservice@beyourlover.com.hk。

**廢物處理**

請依法處理用過的電池。切勿將電子設備或電池丟棄在生活垃圾中。請將其送至相應的廢舊電器或電子產品回收站,以確保環保處理。

**EN**

**Before Use**

Please fully charge our product before the first use. The charging time is about 1 hour, after it's fully charged, the LED light will stay on.


Please remove piercings or jewelry in the nipple, genital, and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.

**Product Specification**

Product Name: SIXTH SENSE  
Product No: HC549A  
Material: Silicone, ABS  
Size: 85mm\*42mm\*24mm  
Weight: 50±5g, 16g  
Battery Type: Polymer lithium battery  
Battery Capacity: 150mAh  
Rated Voltage: 3.7V  
Rated Current: <120mA  
Charging Time: 1H  
Working Time: 1H  
Vibration Mode: 10  
APP Mode: 6 Plays  
Waterproof Rating: IPX6

**How to Use**

**Button Display**




Attach the section by placing it on the outside of the underwear for a more secure fit.

**Power (On/Off)**  
Press the button [ ] for 1.5s to turn on/off the power.

**Vibration Mode**  
Click the button [ ] to change the 10 different vibration modes.

**Remote Controller Mode**  
Click the button [ ] or [ ] to change the 10 different vibration modes.  
Click the button [ ] to pause it. Click the button [ ] or [ ] to resume.

**APP Remote Control**  
Turn on the Bluetooth of your phone and connect the product to the official APP for remote control. More different ways to play on the APP: touch mode, automatic mode, sound mode, music mode, custom mode, and remote mode. (APP can be downloaded by scanning the QR code below)



**LED Display**

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

**Charging**  
Please use the charger provided by the official manufacturer. The cable must dock with magnetic contacts on the toy's metal contact points intended for this purpose. If the charging cable does not adhere to the contact points by itself, connect it to the electrical supply and wait a moment. The magnetic effect will thus be reactivated, and the contacts will connect automatically. Please keep the charging dock dry to avoid affecting the magnetic effect and the charging time should not exceed 12 hours.

**Maintenance**  
This product meets the IPX6 international waterproof standard; it can prevent high-pressure water flow from any angle. Please do not use this product underwater. Only use a water-based lubricant for a better experience. Please clean it every time before and after use. And make it completely dry after cleaning. Please keep it in a dry and safe place with no direct sunlight.

**Warning**

If you have skin allergies or discomfort while using this product, please stop immediately and go to the hospital if necessary. Please read the user manual carefully and use the product safely according to the instructions.

**1-Year Warranty & Customer Service**  
The 1-Year Warranty service will start from the day you purchase the product. Please contact the platform seller or the official email to get the service. Please keep your proof of purchase during the warranty period.  
If you have any product quality-related problems, please take photos as evidence the first time and attach the order information to the seller on your purchase platform for return and exchange. Or contact us by email: afterservice@beyourlover.com.hk

**Waste Disposal**  
Please legally dispose of used batteries. Never throw away electronic devices or batteries in household waste. Please send it to the appropriate waste electrical or electronic recycling station to ensure environmentally friendly disposal.



HC549A 华语 说明书 折页  
尺寸:70×100mm  
材质:80g书纸,双面印刷